


PFM-View Version 1.14



User manual and application instructions

A Counting Solutions software application

Alphen aan den Rijn, August 2002

PFM – View version 1.14, July 2001

General description.

The PFM-View application program is designed to give an easy and quick interface to the counting information data from the PFM counting systems for single and multiple entrance applications.

The application allows you to set up the package for simple or complex multi sensor installations and to define object and zone totals for free selectable periods over day, week or quarter intervals.

The program is designed to run under the Window application programs and offers additional export facilities to both Excel or Word programs.

Installation requirements


The PFM-View application requires the following configuration;

Windows 95 or higher

Installation;

The application will be installed with the SETUP command and run in a dedicated directory i.e. PFM-View in the pogrom files directory. Use UNINSTALL to delete the program

The program.



After starting the PFM-View application the following screen will appear:

After initial installation the program needs to be activated for personal use.

Note: the PFM-View program license relates to the owrkstation. Copying of the program to another station will require an additional set-up code.

To activate the program, click on INSTALL and the following window will appear

Contact your supplier to obtain your Personal authorization code.



To set up the program, follow the instructions as mentioned below.

Setting requirements.

The following information and parameters need to be set to get started with the program;

- The store name relative to the store ID number as used in the data files
- The path where to find the data files
- The column number for each direction of flow to set up the totals calculations
- The general descriptions for the graphs and tables

Click on "Setting" and select "Label ID numbers"

Password verification.	×] pa
Please enter pasword:		L
		Γ
ОК	Cancel	
	Please enter pasword:	Please enter pasword:

👸 P	FM_View	Version	n: 1	.14		
<u>F</u> ile	<u>S</u> ettings	<u>I</u> nstall	<u>A</u> bou	ıt		
D	Label II Define) number Zones	s		Q	
П	Set Language					
	Set data <u>D</u> irectories					
	Edit graphic names					
	Change <u>V</u> iew Settings					
	Change	e passwor	rd			

Note defualt passwords are : USER and SUPERVISOR
(USER for all entries, SUPERVISOR to change the Data Directories)

Enter the three digit ID number and type in the name of the object. If correct click on Ok.

	🕄 Edi	t ID La				I
,	ID 1 ID 2	101	Flucon			Sa
	ID 3 ID 4	000				rday :
ı, Total on, Zoı		000				036 422 0
				Cancel	Ok	0 0
	Locatio	n:		Selection	n:	

Select from the settings menu "Define Zones".

Select the relevant store.

The store totals are predefined. Edit, if applicable, the other zone names


For the store total and zone total The relevant column number must be Defined for the "IN" directions

- 6	Change zone definitions		<□ -
	Select location:		
	Flucon		
			-
			F
	Flucon:		
	Totals in	Edit definition	lay
Tot n, Z	Zone 1	Edit definition	6 2
, 2	Zone 2	Edit definition	Ó
	Zone 3	Edit definition	0
		Edit definition	Ĕ
		Edit definition	
_	Clear UnDo	Ok	
-8			

To do this, click on "Edit Definition"

Select the required channel nr. for all the IN directions and bring them to the right hand column. If all are OK click on the OK button.

Follow this procedure for every zone



At this point the actual installation of the sensors is linked to the program for further calculations. Now we have to define the location of the data files in the system. Note that the location of the files can be on another computer when used in a network environment.

Change Flucon : C:VFFM_View/FLUCON	🖃 c: [] 💽
Change	ABNAMRO CDFOON
Change	CDPRO
Change	internet Explorer 4.0
Change	Cancel Ok

To define the path for the files click on "Set data Directories" under the "Settings" menu.

Select the path by clicking on ; disk first followed by the sub directory structure on that disk. On the left hand side the actual path selection is indicated for the selected store. When multiple stores are configured, each store should be set for the path.

The program is now ready to be used for the different calculations

6	PFM_V	/iew	Version	: 1.14		
E	ile <u>S</u> ettir	ngs	<u>I</u> nstall <u>A</u>	<u>A</u> bout		
	Day to:	tal	Week	Week QF	Month	Quarter

To view the data the following selections can be made:

Data per day, i.e. the intensity level over the day in graph with a total "in" per day part Data per week, i.e. daily totals in graph and tables with a week total table Data per Quarter, i.e. week totals for a 13 week period


At the week level a graph can indicate the difference between 'IN" and "OUT" in %. If the difference is exceeding the 10% + or - marker the actual data from file should be reviewed for any problems. A good quality file should be within a 5% band./

After selecting the required graph, the program will allow you to set the store and/or zone over a selected period.

4,000			r	Location:	Selectio
2,000		🗊 Select date 📃 🗖 🗵) Flucon	Totals in
0		November 2000) Flucon	Zone 1
	Monday Tuesday	Mon Tue Wed Thu Fri Sat Sun	riday	Flucon	
	<u>1</u>	44 30 31 1 2 3 4 5 45 6 7 8 9 10 11 12		_	
	Mone	46 13 14 15 16 17 18 19 47 20 21 22 23 24 25 26	iday		1
	Flucon, Totals in 83 Flucon, Zone 1 56	48 27 28 29 30 1 2 3	0		
	Flucon, Zone 1 56	49 4 5 6 7 8 9 10	0		
		Ok Cancel	0		
		<u></u>	Ľ	Selection:	
Week:	Location:	Selection:		Totals in	
Week 47, 2000	Flucon	Totals in		Zone 1	
Week 47, 2000	Flucon	Zone 1		Totals in Zone 1	
	_			 Zone 2 	
		•		Zone 3	
				Microsoft P 🔗 weekeng.b 🔍 Exploring	

Note: Only when all three variables are selected, the graph and tables can be produced by clicking on

VIEW



If all settings are correct the above sample graph and tables will appear after clicking with the mouse on the VIEW button.

To select additional zones or stores or to compare other time intervals, select to a maximum of five different entries in the relevant section.

If the program is closed with the EXIT button, the last selections will be saved to file. When the program is started again the last View will appear.

With the CLEAR Button all selections will be Cleared. To get a print of the report click on PRINT. The program will allow you to add comments to the Report in the special text box as it appears on the screen.

View	
🕒 Print	
Clear	
🕐 Exit	

gle <u>∋</u> ettings <u>Λ</u> bout				
Day Week We	eek QF Quarter			
3,000 5,000 4,000 2,000 Commente_For Commente				
Wcck:	Location:	Sciection:		View/
WEEK 47, 2000	Fluttin	Trais in	7	
eVeek 47, 2000	Flueon	 Zone * 	-	📇 Print
		•	-	Clear
		•	-	
		•	-	🕐 Exit


After completion of the comments click on the PRINT button and a full report (graph, table and comments) is printed on the default printer of your system. To change the printer selection, use the standard WINDOWWS printer settings to change your default printer setting.

Export facilities

Two more options for the export of data are available:

To export the graph to a *.BMP file. To export the table to a *.XLS file.

The first format will allow you to import the graph in any other Microsoft program. The graph can easily be used in a Word document if more extensive reporting is required.



To achieved this, put the mouse indicator on the graph and double click on the left hand mouse button.

Enter the required name for the graph with the BMP extension and select the path and directory for saving the graph.

To export the tables to an CSV / Excel format file, put the mouse on the table and double click on the left hand mouse button.


	Save table da	ita			? ×	
	Savejn:	🔁 Flucon	• E	<u>e</u> 📰]	
 Monday					urday	Sun
Flucor Fluc:	File <u>n</u> ame: Save as <u>t</u> ype:	CSV files (*.csv)	_	<u>S</u> ave Cancel	Sunda 7717 5351	y Week Tota 45432 31161 0
			 	_		0

Follow the same procedure, i.e. enter the name with the csv extension and select the path and directory.

Other features included in the program are:

Selecting the language:

By clicking on the flag, the standard texts Will be changed to the selected language.



Special note:

For the day view the tables will show day-part totals on the screen. If the day graph is printed, the printout will give hourly totals and the print will be in landscape format.